


MEASUREMENT CHART for Penicap dimensions

Measurements & Sizes:

The Penicap sizes are made according the most common sizes of penis of different individuals, due to our longstanding experience and knowledge of their variety. Our sizes I - V cover about 98% of all sizes, we have ever met. The correct measurement of the circumference behind the glans is most important for a good functionality and comfort.

How to take a measurement:



Measure your erect penis, take with a caliper distances of penisshaft in two planes behind the glans at the most narrow diameter and place the caliper without compression. Subtract 2 mm on each diameter of your measurements, and compare your value after subtraction to the case sizes from the chart below, which comes closest to your values. But it **MUST** always be taller than your limp penis!

Measure several times, and take an average of all measurements.

For men **WITH** a foreskin (MUST be very loose !!!): choose 1 size larger.

Inside dimensions of Penicap (most narrow point behind glans):

Size	Internal diameter Penicap in mm	
	Transverse, 1st. diameter	2nd. diameter
A	26	24
B	28	26
C	30	28
D	32	30
E	34	32
F	36	34